

P/N	Description
46004788	SPANNER - LOWER PIN HEAD
460004785	SPANNER-LOWER PIN NUT
460004821	SPANNER
146-41	BLANKING ADAPTOR
21Y37A	Jacking Pad - Rear Fuselage
21Y413AC	SPANNER - Q FEEL PITOT HEAD
21Y999A	RUDDER PEDAL LOCK
2863T000	TORQUE CHECK/CLEANING TOOL ACM
3550-1-12	TRICKLECHARGER AVRO-12
3550-1-6	TRICKLECHARGER AVRO-6
42-500	TOP SHEATH
460004716	SPANNER - N/WH RETAINING NUT
460004729	SPANNER
460004781	SLEEVE AXL THREAD PROTECTION
460004782	SPANNER M/WH RETAINING NUT
460004941-3	ADAPTER - OIL FILL
704-2383-001	ACARS INTERFACE CABLE
A79-1-001	GERIN 25/100 TEST CAPACITY KIT
AV21002	FLOW CONTR.VALVE FLOW PR.GAUGE
AV29001	FLAP GREASE ADAPTER
B4-30010	RADWECHSELHEBER MLG POS.C
CTS398R169	WATER DRAIN ADAPTERS
CTS401R29A	PAD
CTS422R3A	FLUID SAMPLING VALVE
HC130H0009-000	SAFETY SLEEVE-ROLL, SPOI ACT
HC130H0063-000	EXTRACTOR
HC130H0072-000	EXTRACTOR
HC130H0098-000	TOOL-HOLDING THROTTLE COMP.
HC130H0099-000	TOOL RESTRAINING
HC130H0112-000	SAFETY COLLAR
HC130H0171-000	KEY
HC130H0176-000	ENGINE COWLING DOOR TOOL
HC130H0179-000	Fixture - Backlash Checking
HC130H0179-000	FIXTURE - BACKLASH CHECKING
HC131H0012-006	RIGGING PIN SET
HC131H0044-000	EQUIP-TEST SYST.FRIC.FLY.CONTR
HC131H0065-000	KIT-PROTECT. AILERON HANDWHEEL
HC132H0009-002	GEAR ENGINE HOISTING
HC132H0061-006	JACKING ADAPTER - MAIN WHEEL
HC132H0184-000	SLING - NOSE COWL
HC132H0211-000	SLING - MAIN GEAR DOOR
HC132H0217-000	ENGINE SLING
HC132H0234-000	ATTACHMENT
LTCT12986-01	3 ENGINE FERRY N1 LOCK
LTCT1379-01	PULLER
LTCT13857-01	4TH TURBINE TQ FIXTURE

P/N	Description
LTCT14617-01-CLH	LIFTING TOOL
LTCT28960-01	SCAVENGE OIL TEMP. MONITOR
LTCT7923-02	PULLER KIT
P14600-4H	PITOT TEST ADAPTOR
PV1597A	Flight Line Test Set
RC3013K2A0A03	RADWECHSELHEBER MLG POS.D
RH1029A1A0A01	RADWECHSELHEBER NLG
TOWAVRO-C	SCHLEPPSTANGE-AVRO-RJ85-TOWBAR
ADRJ85-612	Air Data Kit